





LDP-C BOB V3.1

Breakout Board for LDP-C/-CW/-QCW Series

Rev. 1905



- Compatible with all LDP-C/ -CW/ -QCW drivers
- Easy access to all monitor signals
- Connector for trigger input
- Status LEDs
- Current setpoint poti
- Enable switch

Product Description

The LDP-C BOB provides an easy access to all control signals of the LDP-C/-CW/-QCW series. Laser diode current, laser diode voltage as well as inductor current monitor signals are lead to SMC jacks for easy connection of an oscilloscope. A SMC connector for the trigger input is also available. The enable signal is connected to a switch to activate the driver easily. By using the poti the current setpoint can be configured very quickly. Two LEDs indicate the status of the driver. The BOB is powered by the driver. Thus, no additional power supply is required.

Technical Data*

Supply voltage	None (supplied through the driver)
Dimensions in mm Weigth Operating temperature	67 x 100 x 32 54 g -20 to +55 °C

^{*} Technical data is subject to change without further notice.

Compatible Products:

LDP-C Series LDP-CW Series LDP-QCW Series

Germany and Other Countries

Laser Components Germany GmbH
Tel: +49 8142 2864-0
Fax: +49 8142 2864-11
info@lasercomponents.com
www.lasercomponents.com

rance

laser Components S.A.S.
Tel: +33 1 39 59 52 25
Fax: +33 1 39 59 53 50
info@lasercomponents.fr
www.lasercomponents.fr

United Kingdom

Laser Components (UK) Ltd.
Tel: +44 1245 491 499
Fax: +44 1245 491 801
info@lasercomponents.co.uk
www.lasercomponents.co.uk

Nordic Countries

Laser Components Nordic AB Tel: +46 31 703 71 73 Fax: +46 31 703 71 01 info@lasercomponents.se www.lasercomponents.se