


AMAGE-M2 Automated M² measurement system

AUTOMATED MEASUREMENTS



Inside the BEAMAGE-M2, a computer-controlled motorized rail allows precise positioning of two mirrors, which in turn allow a 400 mm beam path difference. At each position of the translation stage, a beam profile is acquired and the beam diameter is measured. The automation of the translation stage allowed by the software is the key to a fast measurement.

KEY FEATURES

LARGE APERTURES

The only M² system on the market equipped with a complete set of 50mm (2") optics. Also, the sensor is 11.3 x 11.3mm

SIMPLE ALIGNMENT

Two beam-steering mirrors are included for quick and easy alignment of your laser into the system.

COMPACT

The low-profile ingenious mechanics make it easy to fit the device on any optical table

ISO COMPLIANT

The calculations are fully compliant to the ISO 11146 and 13694 standards

FAST ACQUISITION

Make a complete, ISO-compliant measurement in only 20 seconds with the ROI feature and in less than a minute with full-frame acquisition

> FLEXIBLE & INTUITIVE SOFTWARE

PRACTICAL ALIGNMENT TOOL

Each BEAMAGE-M2 system includes an alignment tube that helps you set up the system faster. Simply use the two alignment mirrors to center your laser beam onto both irises, and you will be ready to start measuring in no time!

The fluorescent material around the pinholes also helps to align beams that are in the NIR range without having to use an IR viewer.

Germany and Other Countries

Laser Components Germany GmbH Tel: +49 8142 2864-0 Fax: +49 8142 2864-11 info@lasercomponents.com www.lasercomponents.com

France

Laser Components S.A.S. Tel: +33 1 39 59 52 25 Fax: +33 1 39 59 53 50 info@lasercomponents.fr www.lasercomponents.fr

Nordic Countries

Laser Components Nordic AB Tel: +46 31 703 71 73 Fax: +46 31 703 71 01 info@lasercomponents.se www.lasercomponents.se

BEAMAGE-M2 Specifications



	BEAMAGE-M2	
THEOD TECHNICION		
SENSOR TECHNOLOGY	Beamage-4M included	
EFFECTIVE APERTURE	Ø 48 mm optics - 11.3 x 11.3 mm sensor	
MEASUREMENT CAPABILITY	WEA WAA	
System wavelength range	350 - 1100 nm	
Attenuation range	3 Flip-mount attenuators for 8 levels of attenuation: no attenuation, ND0.5, ND1, ND2, ND1.5, ND2.5, ND3, ND3.5	
Beam diameter range ^a	55 μm to 11.3/3 mm	
Translation stage		
Mechanical travel range	200 mm	
Effective optical path range	400 mm	
Lens focal length	5 AR-coated lenses included: 200 mm, 250 mm, 300 mm, 400 mm and 500 mm	
Typical M ² accuracy ^b	±5%	
Typical M ² repeatability ^b	±2%	
Applicable light sources	CW and quasi-CW	
Typical measurement time	45 s with full-frame acquisition	
DAMAGE THRESHOLDS °		
Maximum average power	1 W with ND filter	
Maximum density (1064 nm)	CW: 10 W/cm²; Pulsed: 0.1 J/cm²	
PHYSICAL CHARACTERISTICS		
Dimensions		
Main enclosure	357 mm (L) x 165 mm (W) x 135 mm (H)	
Total (including external mirrors)	602 mm (L) x 193 mm (W) x 172 mm (H)	
Optical axis height	86 mm	
Weight	6.6 kg	
Power supply	48 VDC, 1.25A out	
SOFTWARE		
Displays	2D, 3D, XY, Beam Tracking and M ²	
Beam diameter definitions	D4σ 1/e² along crosshairs (13.5%) FWHM along crosshairs (50%) Custom (%)	
Beam quality definitions	Laser beam quality M_{γ}^2 , $M_{z_y}^2$, $M_{z_y}^2$ (ISO compliant) Beam Propagation Factor: $\mathrm{BPP}_{x'}$ BPP_{y} Width at waist: $\mathrm{W}_{x'}$, W_{y} , W_{y} Waist location and offset: Z_{v_x} , Z_{z_y} , $\Delta\mathrm{Z}$ Divergence angle: g_{z_y} , g_{z_y} Astigmatism	
Printing and reports	Full report in print-ready format	
ORDERING INFORMATION		
Product page		

回数线数

Specifications in the table above are for the use with a Beamage-4M beam profiler (included in the Beamage-M2 kit)

- a. At the Beamage sensor b. Depending on the beam quality and optical configuration c. With ND4 filter at the Beamage

Specifications are subject to change without notice

2

Germany and Other Countries

Laser Components Germany GmbH Tel: +49 8142 2864-0 Fax: +49 8142 2864-11 info@lasercomponents.com www.lasercomponents.com

France

Laser Components S.A.S. Tel: +33 1 39 59 52 25 Fax: +33 1 39 59 53 50 info@lasercomponents.fr www.lasercomponents.fr

Nordic Countries

Laser Components Nordic AB Tel: +46 31 703 71 73 Fax: +46 31 703 71 01 info@lasercomponents.se www.lasercomponents.se





BEA Søftware fe	MAGE-M2 atures	
	Select which set of Rayleigh range boundaries to display on the graph: X, Y or both	M2 Results tab: View and understand all the measured parameters quickly, for both the initial laser beam and the beam inside the BEAMAGE-M2 system
	Switch to 3D or 2D displays to see each of the measured profiles	M2 Setup tab: Control your acquisition parameters

03/24 / V2 / RB-IF / gentec/beamage-m2-measurement-system

3

Germany and Other Countries

Laser Components Germany GmbH
Tel: +49 8142 2864-0
Fax: +49 8142 2864-11 info@lasercomponents.com www.lasercomponents.com

France

Laser Components S.A.S.
Tel: +33 1 39 59 52 25
Fax: +33 1 39 59 53 50
info@lasercomponents.fr www.lasercomponents.fr

Laser Components Nordic AB Tel: +46 31 703 71 73 Fax: +46 31 703 71 01 info@lasercomponents.se www.lasercomponents.se

BEAMAGE-M2

ISO COMPLIANCE MADE SIMPLE

With the "RUN M2 SETUP" button, the software automatically defines new parameters for a more precise ${\rm M^2}$ measurement. The "ISO SCAN" data set complies with the ISO-11146 ${\rm M^2}$ measurement standard, being spread between $-3Z_{R}$ and $+3Z_{R}$

The automatic settings are updated after each calculation, considering the values of Z_0 and Z_R from the latest measurement.

By default, the results graph always shows the calculated positions of the first three Rayleigh distances on each side of the waist.

FULL CONTROL ON YOUR DATA

During an M² scan, each of the measured profiles is saved and the flexible software gives you complete control on your acquired data.

- · View each acquired profile in 2D display or 3D display.
- Add measurement points to a data set at the position of your choice with the "ADD"
- Remove unwanted profiles from your data set & recalculate the measurements.

FAST ATTENUATION

Add or remove attenuation with the flick of a finger. The software adjusts the exposure time at each frame during an acquisition, and advises the user on the required attenuation.

Tel: +49 8142 2864-0 Fax: +49 8142 2864-11 info@lasercomponents.com www.lasercomponents.com

Laser Components S.A.S. Tel: +33 1 39 59 52 25 Fax: +33 1 39 59 53 50 info@lasercomponents.fr www.lasercomponents.fr

Laser Components Nordic AB Tel: +46 31 703 71 73 Fax: +46 31 703 71 01 info@lasercomponents.se www.lasercomponents.se