





ARINC 801

Connector Inspection & Cleaning

Technical Note



REV A





OVERVIEW

ARINC 801, Key Terms & Inspection Overview

Westover Scientific

ARINC 801


Overview

ARINC 801 is the most frequently used specification for fiber optic connectors in aerospace applications. Established by the Airlines Electronic Engineering Committee (AEEC), ARINC 801 is part of the ARINC 800 series of fiber optic standards for avionics networking. All ARINC 801 connectors utilize a 1.25mm ferrule and are mated in a pin & socket configuration. While all of the ARINC 801 connectors utilize a "plug & receptacle" design, there are different design types within the standard.



Key Terms

- Plug: the male interface of an ARINC 801 connection.
- Receptacle: the female interface of an ARINC 801 connection.
- Pin: the exposed 1.25mm ferrules.
- Socket: the unexposed ferrules inside the alignment sleeves.




Inspection Overview

Visual inspection is the only way to validate the condition of a fiber end-face. Proper inspection and cleaning of fiber optic connectivity is vital to the efficiency and longevity of the fiber optic network; failure in doing so can and will lead to costly downtime and permanent damage. Practicing proper inspection methods is critical at installation and throughout the life of the fiber.

You should always INSPECT BEFORE YOU CONNECT...

- Microscopic contamination of fiber optic interfaces compromises optical transmission
- Mating dirty connectors leads to equipment damage and costly downtime
- Debris particles dig into the fiber creating pits, chips and embedded matter
- Contamination must be removed prior to mating connectors







CONNECTOR TYPES & INSPECTION / CLEANING GUIDES

ARINC 801 Connector Types & Inspection / Cleaning Guides

ARINC 801 Connector Types

Type 1: Circular

Type 2: Rectangular

Type 3: ARINC 404A

Type 4: ARINC 600











ARINC 801 Inspection & Cleaning Guides

Westover Scientific offers a series of alignment guides that fit the shell sizes of the respective plug and receptacle of various ARINC 801 connectors. These guides provide a compatible interface for the inspection and cleaning of pins or sockets specific to each type of connector. When used in conjunction with Westover's Professional Series probe microscopes and portable display units, Westover's ARINC 801 alignment guides provide the means for a quick and easy inspection of these rugged, multi-termini connectors, in a field or factory environment. In addition, these guides can also be used with Westover's CleanBlast™ system to clean away debris and dirt from the optical end-faces of ARINC 801 connectivity.

Note: Westover will design and build guides for any ARINC 801 interconnect requested. Below are guides that have already been designed.

Type 1: Circular	Type 2: Rectangular	Type 3: ARINC 404A	Type 4: ARINC 600
333	17 may 19	Engineered to Order	27.72
FBPT-A801-1-001-P	FBPT-A801-2-001-P		FBPT-A801-4-001-P
13-04 Shell, Plug	F12, Pins, Plug		12 Fiber, Plug
Build to Order	In Stock		In Stock
FBPT-A801-1-001-R	FBPT-A801-2-001-R		FBPT-A801-4-001-R
13-04 Shell, Receptacle	F12, Sockets, Receptacle		12 Fiber, Receptacle
Build to Order	In Stock		In Stock
FBPT-A801-1-002-P	FBPT-A801-2-002-P		FBPT-A801-4-002-P
15-06 Shell, Plug	F12, Sockets, Plug		36 Fiber, Plug
<i>In Stock</i>	In Stock		Build to Order
FBPT-A801-1-002-R	FBPT-A801-2-002-R		FBPT-A801-4-002-R
15-06 Shell, Receptacle	F12, Pins, Receptacle		36 Fiber, Receptacle
In Stock	In Stock		Build to Order
FBPT-A801-1-003-P 21-16 Shell, Plug Build to Order			
FBPT-A801-1-003-R 21-16 Shell, Receptacle Build to Order			




INSPECTING & CLEANING

Instruction

Westover Scientific

ARINC 801

Westover Part Numbering Configuration



Example:

FBPT-A801-2-001-R

- ARINC 801
- **-** Type 2
- F12 Shell Size with Sockets
- Receptacle

Inspecting & Cleaning

NOTE:

- For INSPECTION, all A801 guides interface with the FBPP-BAP3 barrel assembly.
- For **CLEANING**, all A801 guides interface with the **FCLT-BAP3-125** cleaning tip.

Tools





Operation



 Select the appropriate alignment guide for the connector being inspected, align the geometry and insert into the connector.



 Insert the probe w/ barrel assembly (FBPP-BAP3) or the CleanBlast™ system w/ cleaning tip (FCLT-BAP3-125) into the guides.



3. Initiate inspection or cleaning.



4